



How to arm/disarm the Bandit II IR Smart Tag

Figure 1



Bandit II IR Smart Tag

Figure 2



Switch to arm tag

Internal lock

How to arm the Bandit II IR Smart Tag

Figure 3



Place the large plunger on the boxed item tag is ready to arm

Figure 4



Affix Bandit II Tag flat on the product slide the switch you will hear a beep the tag is armed.

Figure 5

How to disarm the Bandit II IR Smart Tag

Figure 6



Place the product box with Bandit II IR Smart Tag on place the IR detector close to the internal lock the IR detector will send a signal to turn the tag off the switch will automatically release and disarm the tag.



Place the IR detector close to the internal lock the IR detector will send a signal to turn the tag off the switch will automatically release and disarm the tag.